

# **Lifting Capacities**


PCSA Class 10-84

Hydraulic Crane

GENERAL INFORMATION ONLY

HTC-835 35-ton (31.75 metric ton)

#### **4-Section Boom**



Note: Boom and fly and jib geometry shown are for unloaded condition and machine standing level on firm supporting surface. Boom deflection and subsequent radius and angle change must be accounted for when applying load to hook.

# C-835 Lifting Capacities 8 (2.44 m) carrier

## GENERAL INFORMATION ONLY

Refer to Operating Instructions page 4

32'-101' (9.75 - 30.78 m) 4-section boom

	<b>32</b> ' (9	<b>32</b> ' (9.75 m)		Capacities C (9.75 m) 40' (12.19 m)			48' (14.63 m)		56' (17		Secur 64' (19		72' (21.95 m)		<b>78</b> ' (23.77 m)		78' (23.77 m) boom plus 29' (2.84 m) fly		
Load radius	Side	Rear	Side	Rear	Side	Rear	Side	Rear	Side	Rear	Side	Rear	Side	Rear	Boom	Side	Rear		
10' 3.05m	70,000 31 752	70,000 31,752	51,800 23 496	51,800 23 496	50,900 23 088	50,900 23,088	50,400 22,861	50,400 22,861	41,700 18 915	41.700 18.915									
12' 3.66m	56,500 25 628	56,800 25 764	51,800 23 496	51,800 23 496	50,900 23 088	50.900 23.088	50,400 22 861	50,400 22 861	38,600 17 509	38.600 17 509	32,300 14 651	32,300 14 651			] s	e Note			
15' 4.57m	43,100 19 550	48,200 21 863	43,100 19 550	48,200 21 863	43,000 19 505	48,100 21 818	43,000 19 505	45,900 20 820	34,600 15 694	34,600 15 694	29,200 13 245	29,200 13 245	24,700 11 204	24,700 11 204	] `				
20' 6.10m	30,800 13 971	35,800 16,239	30,800 13 971	35,800 16 239	30,800 13 971	35,800 16 239	30.800 13.971	35.800 16 239	29,200 13 245	29,200 13 245	25,000 11 340	25,000 11 340	22,600 10 251	22.600 10.251	79*	14,500 6 577	14,500		
25' 7.62m	21,500 9 752	26,100 11 839	21,500 9.752	26,100 11 839	21,500 9 752	26,100 11 839	21,500 9,752	26,100 11,839	21,500 9,752	25,200 11 431	21,400 9,707	21,400 9,707	19,400 8 800	19,400 8 800	77*	13,600 6 168	13,600 6 166		
30' 9.14m	-		15,100 6 849	19,100 8 664	15,100 6 849	19,100 8 664	15,100 6 849	19,100 8 664	15,100 6,849	19,100 8 664	15,100 6 849	18,900 8 573	15,100 6 849	17,100 7,756	74*	12,100 5 488	12,100 5 488		
35' 10.67m					11,200 5 080	14,600 6 622	11,200 5 080	14,600 6 622	11,200 5 080	14,600 6 622	11,200 5 080	14.600 6 622	11,200 5,080	14,600 6 622	72°	11,500 5 216	11,500 5 216		
40' 12.19m					8,400 3,810	11,500 5 216	8,400 3,810	11,500 5 216	8,400 3,810	11,500 5 216	8,400 3,810	11.500 5 216	8,400 3,810	11,500 5 216	69°	10,000 4 536	10,500 4 762		
45' 13.72m							6,500 2 948	9.200 4 173	6,500 2 948	9,200 4 173	6,500 2 948	9,200 4 173	6,500 2 948	9.200 4 173	66°	7,900 3 583	8,700 3,946		
50' 15.24m							5,000 2,268	7,400 3 357	5,000 2 268	7,400 3 357	5.000 2 268	7,400 3 357	5,000 2 268	7,400 3 357	63°	6,400 2 903	7,900 3 58		
55' 16.76m									3.900 1.769	6,100 2,767	3,900 1 769	6,100 2,767	3,900 1,769	6,100 2,767	60°	5,100 2 313	7,200 3 265		
60' 18.29m									2, 900 1 315	4,900 2,223	2,900 1 315	4,900 2,223	2.900 1.315	4.900	56°	4,200 1 905	6,100 2 766		
65' 19.81m											2,200 998	4,000 1 814	2,200 998	4,000 1,814	53°	3,400 1 542	5,200 2 358		
2													1,600 726	3,300 1 497	49°	2,700 1 224	4,400 1 995		
75 22.86m															45°	2,100 952	3,700 1 678		
80' 24.38m						·									41°	1,600 725	3,100 1 406		
85' 25.90m															36°	1,200 544	2,600		
90' 27,43m												7			30.		2,100 952		

Note: For 360° capacities, use the over side capacities with the bumper outrigger set in proper working position.

① Capacities for boom plus fly can be extended or retracted, but are based on boom angle only. See Operating Instructions Number 16.

Main Boom Capacities  On Tires										
Load radius			(1.61°km/hr) ear only	Crane capacities on tires depend on tire capacity, condition of tires,						
Feet	meters	Pounds	kilograms		and tire pressures.					
10	3.05	19,500	8 845		Ply	1.0 m.p.h. (1.61 km.hr				
12	3.66	16,000	7 257	Tires	rating	Inflation				
15	4.57	11,700	5 171	10.0 x 20.0	12	65 p.s.i. (4.48 Bars)				
20	6.10	7,300	3 311	11.0 x 20.0	1	55 p.s.i. (3.79 Bars)				
25	7.62	4,600	2 086	16.5 x 22.5	12	90 p.s.i. (6.21 Bars)				
30	9.14	2,800	1 270	10.5 X 22.5	16	90 p.s.i. (6.21 Bars)				
35	10.67	1,600	725			Ė				

Deductions For Load Handling E					
Picking From Main	Boom With				
Aux. Head	200 Lbs				
Jib Stowed	600 Lbs				
Fly Stowed	600 Lbs				
Fly Erected					
Fly & Jib Stowed	1200 Lbs				
Fly & Jib Erected	4200 Lbs				
Picking From 29 F	t. Fly With				
Jib Erected	1300 Lbs.				
Jib Stowed 600 Lbs.					

wile lobe size and the	<b>E</b>	
W ope application	Size and type used	Wire rope description
Mam winch	5/8" (16 mm) diameter, Type "N"	Type "N" - 6 x 25 (6 x 19 class) filler wire, extra
Auxiliary winch	5/8" (16 mm) diameter, Type "N"	improved plow steel, preformed, independent
Jib frontstay pendants ①	1/2" (13 mm) diameter, Type "N"	wire rope core, right lay, regular lay.
Jib backstay pendants 3	1/2" (13 mm) diameter, Type "N"	

<sup>(1)</sup> Jib frontstay pendants - 24" 3-5/8" (7.45 m)





## **HTC - 835 Lifting Capacities**

## GENERAL INFORMATION ONLY Refer to Operating Instructions page 4

8' (2.44m) carrier

32' - 101' (9.75 - 30.78 m)4-section boom

		<b>101'</b> (30.78 n	n)	ual Section Extended  101' (30.78 m) Plus 29' (8.84 m) fly			
Load radius	Boom angle	Side	Rear	Boom angle	Side	Rea	
		See N	lote ①				
20' 6.10 m	79*	14,800 14,800 6 713 6 713			See N	ote ①	
25' 7.62 m	76*	14,300 6 486	14,300 6 486				
30' 9.14 m	74.	13,800 6 259	13,800 6 259	78*	7,000 3 175	7,000 3 175	
35' 10.67 m	71*	12,500 5 670	12,500 5 670	76*	7,000 3 175	7,000 3 175	
40' 12.19 m	68*	9,800 11,100 4 445 5 034		74*	7,000 3 175	7,000 3 175	
45' 13.72 m	<b>65</b> °	7,700 3 <b>49</b> 2	9,900 4 490	72*	7,000 3 175	7,000 3 175	
50' 15.24 m	61*	6,200 2 812	8,600 3 900	70*	6,800 3 084	6,800 3 084	
55' 16.76 m	58*	5,000 2 268	7,200 3,265	67*	5,600 2 540	6,200 2 812	
60' 18.29 m	54*	4,100 1 859	6,000 2 721	65*	4,600 2 086	5,700 2 585	
65' 19.81 m	50*	3,300 1 496	5,100 2 313	62*	3,800 1 723	5,200 2,358	
70' 21.34 m	46*	2,600 1 179	4,300 1,950	60.	3,100 1 406	4,700 2 131	
75' 22.86 m	42*	2,000 907	3,600 1 632	57*	2,600 1 179	4,100 1 859	
80' 24.38 m	37*	1,600 725	3,100 1 406	54*	2,100 952	3,500 1 587	
85' 25.90 m	31*	1,200 544	2,500 1 134	51*	1,600 725	3,000 1 360	
90' 27.43 m	27*		2,100 952	48*	1,300 589	2,600 1 179	
95' 28.95 m				44.		2,200 997	

Note: For  $360^\circ$  capacities, use the over side capacities with the bumper outrigger set in proper working position.

	Jib Ca	pacities						
29' (8.8	34 m) fly p	lus 21' (6.	40 m) jib					
Boom	Jib Offset							
angle	5.	17.5	30°					
80°	4,000	4,000	4,000					
	1 814	1 814	1 814					
75*	4,000	4,000	3,600					
	1 814	1 814	1 632					
70*	3,800	3,300	2,900					
	1 723	1 496	1 315					
65*	2,500	2,200	1,900					
	1 134	997	<i>861</i>					
60.	1,500	1,300	1,200					
	680	589	544					

#### Drum wire rope capacities

	Main and auxiliary drum 10%" (.27 m) root diameter smooth lagging								
Wire	5/8" (16 mm) wire rope								
rope	Rope	per layer	Total v	rire rope					
layer	Feet	meters	Feet	meters					
1	74	22.55	74	22.55					
2	85	25.91	159	48:46					
- 3	90	27.43	249	75.89					
4	98	29.87	347	105.76					
5	106	32.31	453	138.07					
6	115	35.05	568	173.13					
	Main and auxiliary drum 15%" ( 38 m) root diameter grooved lagging								
Wire	5/8" (16 mm) wire rope								
горе	Rope	er layer	Total wire rope						
løyer	Feet	meters	Feet	meters					
1	103	31.39	103	31.39					
2	111	33.83	214	65.23					
3	120	36.58	334	101.80					
4 .	128	39.01	462	140.82					
5	136	41 52	598	182.27					
6 .	144	43.89	742	226.16					

### Line speeds and pulls

		Main or auxiliary winch - 10%" (.27 m) drum							Main or auxiliary winch - 15%" (.38 m) drum						
		Line speeds		Line pulls							Line pulls				
Layer	Speed			Available*		Permissible		Line speeds		Available*		Permissible			
		F.p.m.	m/min.	Lbs.	kgs.	Lbs.	kgs.	F.p.m.	m/min.	Lbs.	kgs.	Lbs.	kgs.		
1st	Low	133	40.54	12,970	5 883	11,700	5 307	186	56.69	9,260	4 200	8,420	3 819		
	High	266	81.08	6,480	2 939	5,890	2 672	372	113.38	4,630	2 100	4,210	1 910		
2nd	Low	148	45.11	11,670	5 207	10,610	4 812	201	61.26	8,570	3 887	7,790	3 533		
	High	296	90.22	5 840	2 649	5, <b>30</b> 0	2 404	402	122.52	4,290	1 945	3,900	1 7 <b>69</b>		
3rd	Low	163	49.68	10,610	4 812	9,640	4 372	216	65.83	7,980	3 619	7,260	3 293		
	High	325	99.06	5,310	2 408	4,820	2 186	432	131.67	3 990	1 809	3,630	1 646		
4th	Low	177	53.94	9,730	4 413	8,840	4 009	231	70.40	7,470	3 388	6,790	3 079		
	High	355	108.20	4,860	2 204	4,420	2 004	462	140.81	3,730	1 691	3,390	1 537		
5th	Low	192	58.52	8,980	4 073	8,160	3 701	246	74.98	7,020	3 184	6,380	2 893		
	High	384	117.04	4,490	2 036	4,080	1 850	492	149.96	3,510	1 592	3,190	1 446		
6th	Low	207	63.09	8,340	3 783	7,580	3 438	261	79.55	6,620	3 003	6,010	2 726		
	High	413	125.88	4,170	1 891	3,790	1 719	522	159.11	3,310	1 501	3,010	1 365		

<sup>\*</sup>Developed by machinery with first layer of wire rope, but not based on wire rope strength.

HTC-835 hydraulic circuit pressure settings								
Function	Pressure							
Boom hoist	2,900 p.s.i. (200.0 Bars)							
Wire rope hoist	2,500 p.s.i. (172.45 Bars)							
Swing	1,500 p.s.i. (103.45 Bars) at port relief							
Innermid telescope	2,500 p.s.i. (172.41 Bars)							
Outermid telescope	2,500 p.s.i. (172.41 Bars)							
Steering	2,100 p.s.i. (144.79 Bars)							
Outriggers	2,500 p.s.i. (172.41 Bars)							
Winch brake and clutch	1,500 p.s.i. (103.45 Bars)							

①Calculating capacities for extended or retracted boom with manual section extended must be based on boom angle only; see Operating Instructions Number 15.

①Capacities for boom plus fly can be extended or retracted, but are based on boom angle only; see Operating Instructions Number 16.

## HTC - 835 Warning and Operating Instructions

d and understand these operating instructions and the 1 values before operating crane. Operation which does follow these instructions may result in an accident.

#### General:

- 1 Rated lifting capacities in pounds as shown on lift chart pertain to this machine as originally manufactured and normally equipped by Link-Belt Construction Equipment Company. Modifications to the machine or use of optional equipment other than that specified can result in a reduction of capacity.
- 2 Construction equipment can be dangerous if improperly operated or maintained. Operation and maintenance of this machine must be in compliance with the information in the operator's parts and safety manuals supplied with this machine. If these manuals are missing, order replacements through the distributor.
- 3 The operator and other personnel associated with this machine shall fully acquaint themselves with the latest applicable American National Standards Institute (ANSI) Safety Standards for cranes.
- 4 The maximum allowable lifting capacities are based on machine standing level on firm supporting surface.

#### Set-Up:

- 1 The machine shall be leveled on a firm supporting surface. Depending on the nature of the supporting surface, it may be necessary to have structural supports under the outrigger floats or cires to spread the load to a larger bearing surface.
- When making lifts on outriggers, outrigger beams must be fully extended with tires free of supporting surface.
- 3 Crane capacities on tires depend on tire capacity, condition of tires, and tire pressure. On-tire picks require lifting from main boom head only on a smooth and level surface. Boom sections must be extended equally. Pick and carry operations are restricted to 1 m.p.h. (1.61 km/hr) maximum speed. The boom must be centered over rear with swinglock engaged and the load must be.

The boom must be centered over rear with winglock engaged and the load must be strained from swinging. Lifts with manual itended, ifly or fly-jib combination erected are prohibited on tires.

- When making lifts on rubber, tires must be inflated to the recommended pressure.
- 5 For machine equipped with front bumper outrigger, the front bumper outrigger must be set in proper working position before swinging boom lengths greater than 32' (9.75 m) 360.
- 6 Outriggers must be set before swinging boom to over side position as defined on working area

#### plate No. 59P0009.

- When installing or removing counterweight, use fully retracted boom only. Do not swing counterweight beyond a 25' (7.62 m) radius. Machine must be on outriggers during this operation.
- 8 For required parts of line see wire rope strength plate.

#### Operation

- Pratton:

  Rated lifting capacities at rated radius shall not be exceeded. Do not tip machine to determine allowable load. For concrete bucket operation, weight of bucket and load shall not exceed 80% of rated lifting capacity. For clamshell bucket operation, weight of bucket and bucket content is restricted to a maximum of 6,000 lbs. (2722 kg) or 80% of rated lifting capacity, whichever is less. For magnet operation, weight of magnet and load is restricted to a maximum of 6,000 lbs. (2722 kg) or 80% of rated lifting capacity, whichever is less. For clamshell and magnet operation, maximum boom length is restricted to 50° (15.24 m) and the boom angle is restricted to a minimum of 35°. Manual extended, fly or fly-jib combinations are prohibited for both clam and magnet operations.
- The crane capacities shown on outriggers do not exceed 85% of the tipping loads and crane capacities shown on tires do not exceed 85% of the tipping loads as determined by SAE crane stability test code J-765a.
- 3 The crane capacities above the bold lines are based on structural strength or hydraulic limitations.
- 4 Rated lifting capacities include the weight of hook block, slings, bucket, magnet and auxiliary lifting devices and their weights must be subtracted from the listed rated load to obtain the net load to be lifted. Also see in-cab capacity chart for deductions for auxiliary head, fly and jib.
- 5 Rated lifting capacities are based on freely suspended loads. No attempt shall be made to move a load horizontally on the ground in any direction.
- 6 Rated lifting capacities are for lift crane service only.
- Do not operate at radii or boom lengths where capacities are not listed. At these positions, the machine can overturn without any load on the hook.
- 8 The maximum loads which can be telescoped are not definable because of variation in loadings and crane maintenance, but it is permissible to attempt retraction and extension within the limits of the load rating chart.
- 9 When either boom length or radius or both are between values listed, the smallest load shown at


## GENERAL INFORMATION ONLY

either the next larger radius or boom length shall be used.

- The user shall operate at reduced ratings to allow for adverse job conditions, such as: soft or uneven ground, out of level conditions, wind, side loads, pendulum action, jerking or sudden stopping of loads, hazardous conditions, experience of personnel, two machine lifts, traveling with loads, electrical wires, etc. Side load on boom, fly or jib is extremely dangerous.
- 11 When making lifts with auxiliary head machinery, the effective length of the boom increases by 2' (.61 m). Effective length of boom is length shown on boom length indicator plus 2' (.61 m).
- 2 Power sections must be extended equally
- The least stable rated working area on outriggers is over the side
- 4 Rated lifting capacities are based on correct reeving. Deduction must be made for excessive reeving. Any reeving over minimum required (see wire rope strength plate) is considered excessive and must be accounted for. Use working range plate to estimate the extra feet or rope then deduct. 72 lb. (.33 kg) for each foot of wire rope before attempting to lift a load.
- 15. For boom lengths less than 101' (32.61 m) with manual extended, the rated loads are determined by boom angle only in the column headed 101' (30.78 m). For angles not shown, use next lower boom angle to determine allowable capacity.
- 16. For boom lengths plus fly less than 107' (32.62 m) with manual retracted or less than 130' (39.62 m) with manual extended the rated loads are determined by boom angle only in the respective column. For angles not shown, use next lower boom angle to determine allowable capacity.
- 17. With front bumper outrigger set, use over side capacity values for 360 degree working area.

  Do not lower 78' (23.77 m) boom below 12 degrees. Do not lower 78' (23.77 m) boom with 19 below 30 degrees. Do not lower 101' (30.78 m) boom with manual extended below 27 degrees. Do not lower 101' (30.78 m) boom with 29' (8.84 m) fly below 40 degrees. Failure to follow Note 18 will result in a tipping condition.
- 18. The 21' (6.40 m) jib capacities are based on main boom angle regardless of main boom length. For angles not shown use next lower boom angle to determine allowable capacity. Capacity values can be used to operate over rear or over side. Warning: do not lower 21' (6.40 m) jib in working position below 60 degrees unless boom is fully retracted.
- The 32' (9.75 m) boom length capacities are based on boom fully retracted. If not fully retracted, do not exceed ratings for the 40' (12.19 m) boom length.

### **HTC-835 Working Areas**



Link-Belt<sup>®</sup> is a registered trademark.

We are constantly improving our products and therefore reserve the right to change designs and specifications.

